

HOW DO YOU WANT TO ATTACH YOUR STROBO ACCESSORIES?

Lastolite™ Strobo START HERE

Direct to Flashgun

- A quick simple method of attaching Strobo accessories to a flashgun.
- Easy to use hook and loop fixing.
- Compact and lightweight.



Start by purchasing any of the products below.

Bracket Only

Universal adaptor attaches directly to your flashgun.



LL LS2601

I want accessories

Starter Kits

Starter kits that include the Direct to Flashgun Bracket. Choose between the Gel Starter Kit and the Honeycomb Starter Kit.



LL LS2605

LL LS2606

I want more accessories

Complete Kit

Direct to Flashgun Bracket, Gel Set & Holders and Honeycomb Set.



LL LS2616

I want more accessories

Ezybox Hotshoe Bracket with Bracket Adaptor

- You may already own the Ezybox Hotshoe Bracket from an existing Lastolite product. **If so, you will require the Bracket Adaptor.**
- Mount your flash and Strobo accessory on to a light stand.



I have the Ezybox Hotshoe Bracket. I require the Bracket Adaptor.

I require the Ezybox Hotshoe Bracket and Bracket Adaptor

Bracket Adaptor

Attaches directly to your Ezybox Hotshoe Bracket.



LL LS2611

I want accessories

Starter Kits

Starter kits include the Bracket Adaptor. Choose between the Strobo Starter Kit and the Barn Door Starter Kit.




LL LS2615

LL LS2614

I want more accessories

Complete Kit

Ezybox Hotshoe Bracket and Adaptor, Gel Set & Holders and Honeycomb Set.



LL LS2617

I want more accessories

Strobo Accessories - Buy any of these accessories to add to your Strobo collection



Gel Set
LL LS2604



Gel Holders
LL LS2603



Honeycomb Set
LL LS2602



Snoot
LL LS2619



Barn Doors
LL LS2620



Gobo
LL LS2625



Nature / Architectural
LL LS2613
LL LS2612